



CGR GHINASSI®

SWITCHES



PART NUMBER	DESCRIPTION	APPLICATION
1004114	SWITCH AS.	416B - 428B - 438B
1006903	SWITCH AS. PRESSURE	769C - 777C - 785B - 789B - 793B
1056117	SWITCH AS. LIMIT	621H - 816F - 938F - 988G - 994H
1056118	SWITCH AS. LIMIT	627H - 950G - 972G - 980G
1060107	SWITCH GP. ROTARY	305.5 - 385B - 432F2 - 980H - M322D
1060180	SWITCH AS. PRESSURE	12H - 140H - 307 - 317 - CS433C
1070611	SWITCH AS. PRESSURE	621F - 623F - 627F - 631E - 826C
1070612	SWITCH AS. PRESSURE	611 - 621F - 623F - 980C - D8R
1070616	SWITCH AS. PRESSURE	430D - 432D - 436C - 438C - 446B
1107887	SWITCH AS. START	430E - 541 - 793F - D11T - IT14G
1145333	SWITCH AS. PRESSURE	315 - 317 - 325 - 330 - 350
1199985	SWITCH AS. PRESSURE	315C - 320D - 385B - M318D - M325D
1251302	SWITCH GP. MAGNETIC	12M - 135H - 140G - 140M - 14M - 160M - 307D - 308C - 308D - 311B - 311C - 311D - 311F - 312B - 312C - 312D
1296466	SWITCH AS. ROLLER	311D - 336D - 446B - 446D - 450E
1327419	SWITCH AS. PUSH BUTTON	527 - 561D - 963 - D3B - D9H
1327450	SWITCH AS. PUSH BUTTON	518 - 657G - 789 - 994 - D11N
1428858	SWITCH AS. START	446B - TH103 - TH62 - TH63 - TH83
1632659	SWITCH GP. START	3196 - 3406E - 3412E - 815B - 950E
1632660	SWITCH AS. START	245 - 312D - 980C - IT28 - M318C
1647577	SWITCH GP. BYPASS	24M - 777F - 836H - 994 - D11T
1654026	SWITCH AS. MAGNETIC	517 - 613C - 797 - 988B - D9R
1673466	SWITCH AS. PRESSURE	160H - 816F - 966G - 972G - D8R
1684609	SWITCH AS. START	3412C - 3456 - C11 - C12 - C15
1718708	SWITCH AS. FLOW	777D - 793D - 994F - D11R
1718709	SWITCH AS. FLOW	5130B - 627G - 637G - 777D
1718710	SWITCH AS. FLOW	245D - 615C2 - 773B - 793B - D11R
1718711	SWITCH AS. FLOW	513D - 637E - 776B - 777C - D11R
1727071	SWITCH AS. PRESSURE	M312 - M318
1744058	SWITCH AS. PRESSURE	M315D - M316C - M318D - M322D - M325C
1973818	SWITCH AS. LIMIT	301.6 - 301.8 - 302.5 - 303.5 - 304.5
2033219	SWITCH AS. TEMPERATURE	428D - 430D - 432D - 438D - 442D
2033220	SWITCH AS. TEMPERATURE	517 - 980F - 980C - D8R - D9R
2033221	SWITCH AS. TEMPERATURE	589 - 611 - 637E - 836 - 980C
2033222	SWITCH AS. TEMPERATURE	950E - 980C - D6G - D8R
2033223	SWITCH AS. TEMPERATURE	963B - 973 - 980C - 990 - D8R
2081093	SWITCH AS. PRESSURE	C3.3 - C4.4 - C9 - CB534C - CS431C
2130677	SWITCH AS. LIQUID LEVEL	311D - 390F - 980K - D6K2 - M330D
2418368	SWITCH AS. MAGNETIC	120H - 120K - 120M - 12H - 12K - 12M - - 135H - 140H - 140K
2526677	SWITCH AS. PRESSURE	319C - 320B - 320C - 321C - 323D

All spare parts listed are interchangeable with genuine ones.
All manufacturer's names, numbers, symbols and descriptions are used for reference purposes only.
Image in this catalogue are purely indicative.



CGR GHINASSI®

SWITCHES

PART NUMBER	DESCRIPTION	APPLICATION
2537910	SWITCH AS. PRESSURE	311C - 312DL - 314DL - 315DL - 319DLN
2666210	SWITCH AS. PRESSURE	319C - 330C - 385B - M322D - M325D
3095768	SWITCH AS. PRESSURE	345C - 345CL - 345D - 345DL - 349D2
3095769	SWITCH AS. PRESSURE	120G - 615C - 950E - 963 - D7H
3095795	SWITCH AS. PRESSURE	320B - 323D - 330C - 541 - 551
3379078	SWITCH GP. MAGNETIC	120M - 1290T - 12M - 140M - 14M - 160M -
3495383	SWITCH AS. PRESSURE	315C - 320D - 385B - M318D - M325D
3917125	SWITCH GP. BYPASS	24M - 777F - 836H - 994 - D11T
4556633	SWITCH AS. START	3412C - 3456 - C11 - C12 - C15
2M9346	SWITCH AS. PRESSURE	120G - 120H - 12G - 12H - 130G - 135H - 140G - 140H - 143H - 14G - 14H160G - 160H - 16G - 16H
2S2342	SWITCH AS. HEAT START	12F - 641 - 972G - D346 - D6C
3D9718	SWITCH AS. PUSH BOTTON	120 - 12E - 140 - 14E - 16 - 16G - 206 - 212 - 214B - 215 - 224B - 225 - 227 - 235 - 245 - 615 - 621B - 621R - 623 - 627 - 627B - 631C - 637 - 637D - 641B - 657 - 657B - 666
3E0156	SWITCH AS. START	247 - 442D - D5N - D6T - D8R
3E2026	SWITCH AS. PRESSURE	535B - 740 - 928G - 963C - D6M
3E2030	SWITCH GP. FLOW	583R - 621F - 623F - 627F - D8R
3E6451	SWITCH AS. TEMPERATURE	777D - 963B - 980C - D8R - IT28F
3E7691	SWITCH AS. PRESSURE	130G - 627 - 769C - 773B - 776
3E7692	SWITCH AS. PRESSURE	225B - 436 - 589 - D11N - D9N
3E7789	SWITCH AS. STOP	3408B - 3408C - 3412B - 3412C
3E9367	SWITCH AS. BALL	12H - 120H - 140H - 160H
3K1650	SWITCH AS. LIGHT	528B - 530B - 910 - 930T - 966C
3N5979	SWITCH GP. ROTARY	3406C - 3412C - 3508 - 3516B - G3306
3T2357	SWITCH AS.	317 - 325 - 330 - 350 - 375
3T3132	SWITCH AS. LIMIT	16G - 330L - 631E - 938F - IT28F
3T3133	SWITCH AS. PUSH BOTTON	D11T - D5R2 - D6T - D8T - D9T
3T3453	SWITCH AS.	D10T2 - D11T - D6T - D9T - PL87
3T4418	SWITCH AS. PRESSURE	16G - 651E - 793B - 825C - IT28B
3T5825	SWITCH AS. TEMPERATURE	578 - D4H3 - D5H2 - D8R
4D4785	SWITCH AS. PRESSURE	816B - 977K - 992C - D300B - D9H
4Y0346	SWITCH AS.	572G - 950E - 973 - 980C - D6H
5L5500	SWITCH AS. PRESSURE	826C - 936E - 953B - 992C - D9L
6G4195	SWITCH AS. LIMIT	611 - 613C - 615C - 621E - 621F - 623E - 623F - 627E - 627F - 631E - 637E - 651E - 657E - 784B - 785 - 785B - 789 - 789B - 793B - 793C - 793D - 793F - 797F - 902 - 906 - 908 - 910G - 914G
6I5088	SWITCH AS. PUSH BOTTON	528B - 587R - 651E - 980F - D8R
6T4949	SWITCH AS. PRESSURE	931 - D5C - D5H - D6H - IT12B
7N0718	SWITCH AS. DISCONNECT	725 - 980C - D350E2 - D4C3 - D9T
7N0719	SWITCH AS. DISCONNECT	316F - 349D2 - 990K - D10N - M325C
7N4160	SWITCH GP.	140G - 16G - 572G - 633 - D9H
7N8001	SWITCH AS.	120G - 12G - 130G - 140G - 143H - 14G - 160G - 163H - 16G - 215 - 215B - 215C - 215D - 219D - 225 - 225D - 227 - 229 - 229D - 235 - 235B - 235C - 245 - 245B
7N8005	SWITCH AS.	438 - 589 - 615C - 980C - D8R
7N9560	SWITCH AS. TEMPERATURE	589 - 611 - 637E - 836 - 980C
7S6402	SWITCH AS. LIGHT	130G - 977L - D6E - D7G - D8K
7T0988	SWITCH AS. PRESSURE	535B - 740 - 928G - 963C - D6M
7V5647	SWITCH AS. LIMIT	793D - 826C - 980F - G936 - IT28B
7W1238	SWITCH AS. PRESSURE	206 - 214 - 216 - 224 - 228 - 236 - 247 - 248 - 267 - 287 - 416 - 416B - 416D - 424B - 424D - 426B - 428B - 438B - 446 - 446B - 906 - 914G - 924G - 928G - 938G
7Y3918	SWITCH AS. START	426C - 428C - 436C - 438C - TH63
8C3569	SWITCH AS. TEMPERATURE	135H - 322L - 637E - 960F - D8R
8D2676	SWITCH AS. TOGGLE	651E - 953 - 980C - D11N - D9N

All spare parts listed are interchangeable with genuine ones. All manufacturer's names, numbers, symbols and descriptions are used for reference purposes only. Image in this catalogue are purely indicative.

SWITCHES



CGR GHINASSI®

PART NUMBER	DESCRIPTION	APPLICATION
8P0230	SWITCH AS. PUSH BUTTON	583 - 943 - 973 - D6D - D9H
8V7195	SWITCH AS.	518C - 930T - 950 - D350C - D40D
8Y7237	SWITCH GP. ROCKER	428C - 436C - 438C - 446B - 637E
9F3099	SWITCH AS. MAGNETIC	769C - 972G - 977 - 980C - 988B
9G5517	SWITCH AS.	910 - 935C - D3C - D4C - IT12
9G7641	SWITCH AS. START	428D - 430D - 432D - 442D - 446D
9G8009	SWITCH AS. PRESSURE	446 - 5080 - 953B - 980F2 - D11N
9G8010	SWITCH AS. PRESSURE	730 - 740 - R1700G - TH35
9G8011	SWITCH AS. PRESSURE	651E - 772B - 992C - D10 - IT18B
9P9520	SWITCH AS. PRESSURE	318B - 320BN - 322BL - 325BLN - 330BL
9R9868	SWITCH AS. PUSH BUTTON	416D - 422F - 446B - 450F - TH460B
9W1077	SWITCH AS. START	312B - 314 - 315BL - 317BL - 325C
9X0023	SWITCH AS. ROLLER	140G - 438C - 933C - 992D - D4C
9X4276	SWITCH AS. PRESSURE	789 - 826C - 966R - 983 - D9H
9X4959	SWITCH AS. PUSH BUTTON	910F - 966F - 980F2 - 994D - IT28F